


)



Specifications for HighStrengthFAST 1.0 Wastewater Treatment System 1. GENERAL

The contractor shall furnish and install (1) HighStrenathFAST 1.0 treatment system as manufactured by Bio-Microbics, Inc. The treatment system shall be complete with all needed equipment as shown on the drawings and specified herein.

The principal items of equipment shall include FAST® system insert, lea extensions, or lid. blower assembly, blower controls and glarms. All other items will be provided by others. The HighStrength 1.0 unit shall be situated within a 750 Gallon [2800L] minimum compartment as shown on the drawings. Suggested maximum settling zone is (1X) the daily flow. Tank must conform to local, state, and all other applicable codes. The contractor shall provide coordination between the FAST system and tank supplier with regard to fabrication of the tank, installation of the FAST unit and delivery to the job site.

2. OPERATING CONDITIONS

The HighStrengthFAST® 1.0 treatment system shall be capable of treating the wastewater produced by non-residential or commercial facilities provided the waste contains nothing that will interfere with biological treatment. The FAST system is a biological treatment system not meant for non-biodegradable or industrial wastewater. Consult factory for proper sizing and usage.

The FAST media shall be manufactured of rigid PVC, polyethylene, or polypropylene and it shall be supported by the polyethylene insert. The media shall be fixed in position and contain no moving or wegring parts and shall not corrode. The media shall be designed and installed to ensure that sloughed solids descend through the media to the bottom of the septic tank.

The HighStrength 1.0 unit shall come equipped with a regenerative type blower capable of delivering 20-45 CFM [38-85 m3/hr]. The blower assembly shall include an inlet filter with metal filter element.

5. REMOTE MOUNTED BLOWER

The blower must not set in standing water and its elevation must be higher than the normal flood level. A two-piece, rectangular housing shall be provided. The discharge air line from the blower to the HighStrength System, shall be provided and installed by the contractor.

6. ELECTRICAL

The electrical source should be within 150 feet [45 meters] of the blower, consult local codes for longer wiring distances. All wiring must conform to all applicable codes (IEC, NEC, etc.). Wiring distances must prevent significant voltage loss. Input power on 60Hz electrical system is 110/220 VAC, single phase, 4,6/2,3 FLA, Actual power consumption varies with site conditions. Three phase 50 & 60 Hz options are also available. All conduit and wiring shall be supplied by contractor.

7. CONTROLS

The control panel provides power to the blower with an alarm system consisting of a visual and audible alarm capable of signaling blower circuit failure and high water conditions. The control panel is equipped with SFR® (Sequencing Fixed Reactor) timed control feature. A manual silence button is included.

8. INSTALLATION AND OPERATING INSTRUCTIONS

All work must be done in accordance with local codes and regulations. Installation of the FAST 1.0 shall be done in accordance with the written instructions provided by the manufacturer. Manuals shall be furnished, which will include a description of system installation, operation, and maintenance procedures.

9. FLOW AND DOSING

FAST systems have been successfully designed, tested and certified receiving gravity, demand-based influent flow. Consult factory for guidance when influent flow is controlled by pump or other means to help with highly variable flow conditions. Multiple dosing events should be used to maximize performance.

10.WARRANTY

Bio-Microbics, Inc. warrants all new commercial FAST ® models (HighStrengthFAST® 1.0, 1.5, 3.0, 4.5 and 9.0) against defects in materials and workmanship for a period of one year after installation or eighteen months from date of shipment, whichever occurs first. All are subject to the following terms and conditions below:

During the warranty period, if any part is defective or fails to perform as specified when operating at design conditions, and if the equipment has been installed and is being operated and maintained in accordance with the written instructions provided by Bio Microbics, Inc., Bio-Microbics, Inc., will repair or replace at its discretion such defective parts free of charge. Defective parts must be returned by owner to Bio-Microbics, Inc., is factory postage paid, if so requested. The cost of labor and all other expenses resulting from replacement of the defective parts and from installation of parts furnished under this warranty and regular maintenance items such as filters or bulbs shall be borne by the owner. This warranty does not cover general system misuse, aerator components which have been damaged by flooding or any components that have been disassembled by unauthorized persons, improperly installed or damaged due to altered or improper wiring or overload protection. This warranty applies only to the treatment plant and does not include any of the structure wiring, plumbing, drainage, septic tank or disposal system. Bio-Microbics, Inc.

such things as, but not limited to, defect in design, material, or workmanship, or delays in delivery, replacements or repairs. THIS WARRANTY IS IN LIEU OF ALL OTHER WARRANTIES EXPRESS OR IMPLIED. BIO-MICROBICS SPECIFICALLY DISCLAIMS ANY IMPLIED WARRANTY OF MERCHANTABILITY OR FITNESS FOR A PARTICULAR PURPOSE.

reserves the right to revise, change or modify the construction and/or design of the FAST system, or any component part or parts thereof, without incurring any obligation

to make such changes or modifications in present equipment. Bio-Microbics, Inc. is not responsible for consequential or incidental damages of any nature resulting from

NO REPRESENTATIVE OR PERSON IS AUTHORIZED TO GIVE ANY OTHER WARRANTY OR TO ASSUME FOR BIO-MICROBICS, INC., ANY OTHER LIABILITY IN CONNECTION WITH THE SALE OF ITS PRODUCTS. Contact your local distributor for parts and service.


DO NOT SCALE **UNLESS NOTED DIMENSIONS** ARE IN INCHES [CENTIMETERS] TOLERANCES ± 0.02 IN/IN

[± 0.05 CM/CM]



HighStrengthFAST 1.00 FAST Unit

WEIGHT lb SIZE DRAWING NUMBER SHFFT DATE NAME HSFAST®1.0 Specification 3 OF 4 12/18/2006 DRAWN CHECKED PF 10/8/2013 REVISED 10/8/2013



Notes

- 1. Secure leg extension to the FAST® unit by placing two screws on each side of the leg extension (4 screws per foot are included).
- 2. Cut 4" schd. 40 PVC pipe (not included) to obtain the desired height. Minimum pipe length of 6 1/8" [15.56cm] will provide minimum clearance of 6 3/8 inches [16.2 cm]. For heights greater then 18" [45.7cm] use schol. 80 PVC pipe (not included). Consult factory for extending leg beyond 36"[9cm].

 Anchor the leg extensions to the tank with non-corrosive hardware (not included) at the provided mounting points.
- If less than the minimum of 6 3/8 inches [16.2 cm] is used between the lowest point of the insert and the base of the tank, consult factory for auidance.
- The air supply line into the FAST® unit must be secured to prevent vibration induced damage. The air supply line should be secured with a non-corrosive clamp every 2ft [0.6m] minimum.
- 6. Tank, anchors, piping conduit, blower, housing pad and vents are provided by others.

DO NOT SCALE

UNLESS NOTED DIMENSIONS ARE IN INCHES [CENTIMETERS] TOLERANCES ± 0.02 IN/IN [± 0.05 CM/CM]



HighStrengthFAST 1.00 FAST Unit

WEIGHT lb DRAWING NUMBER SIZE SHEET NAME DATE HSFAST® 1.0 Details DRAWN CTC 12/18/2006 4 OF 4 CHECKED PF 10/8/2013 REVISED 10/8/2013 REV. INI-07-O